



BROWNING

TRAIL CAMERAS

BROWNING TRAIL CAMERA EXTERNAL BATTERY PACK

Thank you for purchasing a Browning Trail Camera Power Pack. Simply follow the setup instructions below to get started. Our customer service team is here to help you with any questions you may have setting up your External Battery Pack to your Browning Trail Camera. Our representatives are available Monday - Friday from 8am to 5pm CST.
Toll Free Customer Service: 1.888.618.4496
www.browningtrailcameras.com

STEP 1: BATTERY INSTALLATION

Press the Battery Eject button on the front of the External Battery Pack. The battery tray will eject about 1/2". With a slight pull, the tray will completely eject.

Insert 8 AA alkaline or lithium batteries. Make sure you install the batteries with the correct polarity, following the markings on the battery tray. For optimal performance we recommend using Browning branded batteries, Energizer™ or Duracell™.

After inserting the batteries, reinstall the battery tray into the External Battery Pack.

We DO NOT recommend using rechargeable batteries in the Battery Pack or Trail Cameras.

We DO recommend that you also have AA batteries installed in the camera when using the External Battery Pack.



Batteries not included

STEP 2: BATTERY TEST

To test the batteries in the External Battery Pack, press the battery test button. There are LED lights that will illuminate to indicate the battery life remaining.

4 LEDs (red, orange, yellow, green) = 100%
2 LEDs (red, orange) = 50%

3 LEDs (red, orange, yellow) = 75%
1 LED (red only) = 25%

STEP 3: CONNECTING THE BATTERY PACK

Open the rubber cover on the bottom of your trail camera's external power port. You will notice the power connector and power jack are "keyed". Simply line up the tabs on the power connector and the camera's power port. When the plug is completely pushed in, twist the connector 90 degrees to lock the connector in place.

STEP 4: MOUNTING TO A TREE

With the strap provided, mount the Battery Pack to a tree next to your camera. You can also hang the Battery Pack on the same strap used to mount your camera to the tree. There is also an attachment built into the back of the battery pack that fits a 5/16" cable lock for added security.

